Motion Detection Setup – Avenger NVR

Start by going into SETTINGS > CHANNEL > SCHEDULE RECORD.

In here you will need to;

1 - Tick "Enable Recording"

2 - Tick "All Day Recording"

3 - Select "Motion"

4 - Click "Copy To.." and select all channels.

Once the above is complete click "Apply"

Next select "Motion" from the sub menu.

In here you will need to;

1 - Select which channel you wish to configure.

2 - Tick "Enable Motion Detection"

3 - Click "Setting" for "Area Setting", in here click and drag the red square so it covers the entire screen and press okay.

4 - Click "Settings" for Linkage, in here you will need to tick the linkage box which corresponds to the channel you are configuring. (for example; if you are configuring channel1 tick CH1 in linkage.)

Once the above is complete press APPLY and motion detection is set!